

QUICK START GUIDE FOR INSTALLING DECKING WITH



DRIVING COLLATED SCREWS (FACE COMPOSITE, FACE BUGLEHEAD, EDGE SCREWS)

- **Do not use** an impact driver or drill
- Set the drill to its **highest torque setting or Drill mode**
- Match the correct color-coded Edge, Clip and Face guides to the color band on driver bits to ensure correct bit is installed in the CAMO® DRIVE™.
- **Engage the bit with the screw** by pushing the drill down prior to running the drill and fastening
- Always drive the screw at **full speed**
- Rest the Edge or Face guides **flat on the face of the board** for proper drive angle
- **Let the screw do the work.** Apply solid pressure to the DRIVE™ handle, and ease into pressuring the drill to drive the screws.
 - With Edge screws, **too much pressure on the drill prevents the screw from boring material out of the board**, which can cause screw slipping with solid PVC or composite materials, cracking or splitting of wood materials (especially hardwoods), and “mushrooming” of composite boards
 - With collated color match composite face fasteners, **too much pressure can cause composite boards to “mushroom or “crack**
- **Lift the DRIVE™ up fully after driving each screw** to feed the next screw into position



DRIVING CLIPS (EDGECLIP™ OR EDGEXCLIP™)

- **Do not use** an impact driver - only drill with torque adjustments
- **Set the drill to 1/3 of max torque** when using the DRIVE™. If the drill has both a Drill mode and Clutch mode, set it to **Clutch mode**.
- **Engage the bit with the screw** by pushing the drill down prior to running the drill and fastening
- Always drive the screw at **full speed**
- **Only use EDGECLIPS™ and EDGEXCLIPS™ between two boards.** Use Starter Clips on the outside groove of your first and last board.
- For 90° pattern, **EDGEXCLIPS™ will also work with** butt joints, joists that have blocking/bridging support, and rim joists against the side of the house. EDGECLIPS™ can be used in place of EDGEXCLIPS™ if both legs are broken off.
- **Set multiple boards and clips at a time.** Push the group of boards tightly together so that they are evenly spaced. Once boards are in position:
 1. **Fasten a clip every 4 ft. or 3rd joist on the outermost board.** This will keep the inner boards in position and prevent the outermost board from tipping up.
 2. Fasten down all clips between the inner boards, then fasten the remaining clips on the outermost board
 3. Follow the same process and continue to set and secure a new group of boards and clips next to what you just installed
- **Break off the EDGECLIP™ legs** where they overhang on the exterior side (i.e. rim joist with fascia) after driving in the clip

