







**DESIGN**


**PURCHASE**


**CONSTRUCT**

**ENJOY**




**Installation Instructions,**  
56610 8" Post to Beam (P2B-LS-8)  
51710 8" Post to Beam (P2B-IW-8)  
54210 Lite 8" Post 2 Beam (8- P2B-LSL)  
52110 Lite 8" Post 2 Beam (8- P2B-IWL)  
56635 6" Post to Beam (P2B-LS-6)  
51735 6" Post to Beam (P2B-IW-6)








# Printing Documents from ISSUU

Unfortunately, there is currently no way to print content directly through issuu. To print a publication, you will need to download it and print it from your computer.






56610




56635




## Laredo Sunset

Installation Instructions, 5XX10 & 5XX35




54210




## Laredo Sunset Lite

Installation Instructions, 5XX10 & 5XX35




51710



51735

**Ironwood**


Installation Instructions, 5XX10 & 5XX35



## Suggested Tools


(others may be required)

Installation Instructions, 5XX10 & 5XX35




## step 1

Installation Instructions, 5XX10 & 5XX35





## step 2





### step 3

Installation Instructions, 5XX10 & 5XX35



## step 4

Installation Instructions, 5XX10 & 5XX35