




## Assembly Instructions



# TXC71

## Rockport Club Sofa

### ..... 20-Year Warranty .....

To view our full warranty, please visit  
[trexfurniture.com/warranty](http://trexfurniture.com/warranty)

### ..... Share your space .....

We love to see where our furniture ends up — snap a pic and share it with us on Facebook!  
[facebook.com/trexfurniture](https://www.facebook.com/trexfurniture)

### ..... Having Trouble? .....

If you have questions or concerns regarding assembly instructions or missing parts, please contact us at (877) 907-TREX (8739) or email [support@trexfurniture.com](mailto:support@trexfurniture.com)

### ..... Cleaning Tips .....

Keep your Trex Outdoor Furniture™ looking brand new:

#### **For a quick clean:**

Simply wipe down with soap and water.


#### **For a deeper clean:**

You'll need:

- » 1/3 bleach and 2/3 water solution
- » clean cloth
- » soft bristle brush

Wipe on solution with your cloth and let it sit on the lumber for a few minutes (this will not affect the color). Then, loosen any dirt and debris that may catch in surface grooves with a soft bristle brush; hose down to rinse.

# TOOLS




4mm T-handle hex key (included)




4mm hex, straight, for drill (included)


## TXC47X -RH/LH MODULE PARTS



## TXC23C -CENTER MODULE PARTS



**A** x 20




3" Screw — H.27X3

**B** x 8




1.75" Bolt — H.25-20X1.75

**C** x 4




.75" Bolt — H.25-20X.75

**1**




Repeat this step for (3) sections

**2**




**3**




**4**

TXC23C



**5**



**6**

